


SWAM-BLASTER® Model MV-2L/EV-2L Abrasive Flow Component Chart

* PRIMARY WEAR PARTS: Frequent inspection and replacement of these parts is necessary to assure proper operation of your SWAM-BLASTER and to prevent excessive wear of those parts which are not directly in the abrasive patch.

For components and their part number not shown on this chart, refer to your model MV-2/MV/2L operating and Maintenance Manual.



CRYSTAL MARK INC.
A SWAN TECHNOLOGIES CORPORATION

613 Justin Avenue-Glendale, California 91201-2396
(818)240-7520 (800)659-7926 FAX (818)247-3574
www.crystalmarkinc.com-sales@crystalmarkinc.com
SWAM BLAST IS A TRADE MARK OF **CRYSTAL MARK INC.**