



SWAM-BLASTER®

Model MV-241 Abrasive Flow Component Chart

* PRIMARY WEAR PARTS: Frequent inspection and replacement of these parts is necessary to assure proper operation of your SWAM-BLASTER and to prevent excessive wear of those parts which are not directly in the abrasive patch.

ABRASIVE NOZZLE.
REFER TO THE
SWAM-BLASTER ABRASIVE NOZZLE CHART
FOR NOZZLE PART NUMBER

For components and their partnumber not shown on this chart, refer to your model MV-241 operating and Maintenance Manual.



CRYSTAL MARK INC.

A SWAN TECHNOLOGIES CORPORATION

613 Justin Avenue-Glendale, California 91201-2396
(818)240-7520 (800)659-7926 FAX (818)247-3574
www.crystallmarkinc.com-sales@crystallmarkinc.com
SWAM BLAST IS A TRADE MARK OF **CRYSTAL MARK INC.**

Rev. E
2/2014